

# Quick Connectors for Power

## Quick Guide by Dotworkz, Inc.

### # CU-QCP-1

#### Cable Specification Requirements for Field Installable Plug

Range for Round Cable Diameter: 0.39 - 0.54" (10 - 13.5 mm)

SJ00T or Equivalent Recommended for Outdoor Use

Contacts UL/ CSA Rated to 9 amps, up to 600 V, 105 C



Figure 1

1) Note: Position of polarity Key in figure 1, positioned below Bottom pin for all of following views. This is nearest to ground pin.



Figure 2

Disassemble Field Installable Plug

- |    |  |
|----|--|
| 1) | Plug Head w/ conductor screw terminal clamps |
| 2) | Coupling Shell                               |
| 3) | O-Ring Seal                                  |
| 4) | Compression Bushing                          |
| 5) | Compression Nut                              |



Figure 3

2) Feed Parts Over Round Weather-Rated Cable as Shown

#### 3) Cable Stripping Guidelines

Outer Sheath: approx. 1 1/4"

Conductors: approx. 1/3"

Max conductor diameter: 16 gage

or use larger Stranded Conductors trimmed to 16 gage or thinner.

4) From Rear View of Plug Head at wire clamp holes, as shown in figure 4

Loosen 3 screw clamps with flat blade size (-1) screw driver, to allow conductors to enter. Top 2 screws for wire clamps are shown in figure 5

5) Insert and securely tighten each screw terminal onto each of three stripped conductors as shown in figure 5

Lowest hole is Safety Ground Wire (green) Nearest to Polarity Key

Left Upper: Neutral (white)

Right Upper: Hot / Line (black)



Figure 4



Figure 5



Figure 6



Figure 7



Figure 8



Figure 9

6) Holding head in place, screw Coupling Shell to Plug Head Securely.

7) Nest Compression Bushing over O-Ring Seal, then push and seat assembly into rear of Coupling Shell.

8) Screw on Compression Nut to Coupling Shell and secure firmly with wrench for good seal. Do not over-tighten.

Plug is now ready for Mating with compatible Pre-Installed Panel Mount Outlet.

# Dotworkz Installation Guide for Panel Mount Quick Connector

## Wiring Color Code

Panel Mt Wire	Conductor ID	Typ. US Color Code
---------------	--------------	--------------------

Green/ yellow	= Ground	= Green
---------------	----------	---------

Brown	= Line / Hot	= Black
-------	--------------	---------

Blue	= Neutral	= White
------	-----------	---------




Figure 1



### Parts of Panel Mount Quick Connector

- 1) Panel Mount Quick Connector
- 2) O-Ring Seal
- 3) Panel Nut




Figure 2

- 1) Install O-Ring Seal over rear threads Panel Mount (Wire Side) as shown




Figure 3

- 2) Install Panel Mount as shown from outside of enclosure, with washer on this side, & Polarity Key positioned at bottom



Figure 4

- 3) Install Panel Nut from Rear of Quick Connector, on inside of Enclosure



Figure 5

- 4) Firmly but carefully Tighten Nut. Do not over tighten +/- 1/4 turn beyond finger tight, to avoid stripping threads on nut.