Strapping Slots for BR-MPM2 & Installing with Accessory BR-MPM2-AC Kit

BR-MPM2: Bare Mount

KT-CDR2: 1 Integrated Power Supply KT-CDR3: 2 Integrated Power Supplies





Image 1) Center Slots for strapping Start strapping from rear, this view show slot arrows shown on face

BR-MPM2-AC (Accessory Sold Separately) Strap slots indicated by arrows



Strapping is threaded from rear thru slots indicated. Face view shown

Assembly mated for pole mounting (Fasteners not shown)



When Bracket is <u>used alone</u>, ½" wide stainless strapping can be used either image 1) on center slots for smaller dia. poles, or image 2) on side slots



Image 2) Side Slots for Strapping Start strapping from rear, this view shows slot arrows from rear view

BR-MPM2-AC mates & nests into rear of BR-MPM2 bracket



When BR-MPM2-AC is Used, sides have %"-20 threaded Inserts to mate to BR-MPM2, Use 6 bolts provided to mate. Use center strapping slots for pole mounting

Assembly reverse mated for wall mounting, or use with pole or parapet mount

